Mounting instruction: Skamol Glue

1 Cut a small hole in the corner of the Skamol Glue bag.

2 Press the Skamol Glue bag to remove the air from the bag.

3 The SkamoEnclosure Glue can now be applied.

A Remove dust from the surface of the SkamoEnclosure Board.

B Use Skamol Primer at the surfaces of the SkamoEnclosure Boards where the Skamol Glue will be applied.

C Add Skamol Glue on top of the SkamoEnclosure Board in a even layer.

D Push the SkamoEnclosure Boards in place. Remember Skamol Glue binds quickly.

E There is no curing time when the SkamoEnclosure Boards are glued, and you can insert the stove immediately.

F Remove the excess Skamol Glue liquid with a wet cloth. Remove the hardened Skamol Glue with a putty knife.